DES **PERCEPT**

PERCEPT Body Camera /

Genetec™ Security Center

Deployment Guide

Document Date: August 14th, 2023

Contents

1	Int	rod	uction4
2	Re	com	nmended Deployment4
	2.1	Lay	yout4
	2.2	Av	ailable Functionalities6
3	Со	nfig	uring the PERCEPT Body Camera7
	3.1	De	ploying Multiple PERCEPT Body Cameras7
	3.2	Со	nfigure Networking7
	3.2	2.1	Configure Cellular7
	3.2	2.2	Configure Cellular Data Usage8
	3.2	2.3	Configure Wi-Fi Data Usage9
	3.2	2.4	Configure Docking Station(s)10
	3.3	Со	nfigure Video12
	3.3	3.1	Disable orientation metadata12
	3.3	3.2	Video profiles13
	3.4	Se	tup local recording on the body camera15
	3.5	Se	tup time synchronization16
	3.!	5.1	Setting NTP in PERCEPT Body Camera17
	3.!	5.2	Pushing NTP Settings from GSC18
	3.6	Cre	eate a new dedicated ONVIF user (recommended)19
4	Со	nfig	uring VPN20

	4.1 V		N requirements
	4.2	VPI	N example
	4.	2.1	Configure L2TP server21
	4.	2.2	LAN IP address reservation22
	4.	2.3	VPN IP address reservation24
	4.	2.4	Configure PERCEPT VPN Settings26
5	In	tegra	ating the PERCEPT Body Camera in GSC27
	5.1	Eni	roll Camera27
	5.2	Co	nfigure Camera
	5.	2.1	Identity
	5.	2.2	Peripherals
	5.	2.3	Video32
	5.	2.4	Recording
	5.	2.5	Video analytics
	5.	2.6	Panormorph Lens
6	Со	onfig	uring Edge Storage Transfer
7	Va	lidat	ing the Integration
	7.1	On	-Demand Streaming
	7.2	Liv	e Streaming
	7.3	Edg	ge Storage Transfer41
	7.4	Ne	twork Interface Switching44

1 Introduction

One of the unique features of the IONODES PERCEPT Body Camera is that it is an open platform device, allowing for integration with industry-leading VMS solutions such as Genetec[™] Security Center. It implements extensive features of ONVIF profiles G, S and T, along with flexible network configurations (LAN, Wi-Fi, 4G/LTE) for live video and edge recording retrieval.

This integration is supported as of IONODES PERCEPT Body Camera firmware 10.7.2.7 and has been validated with Genetec[™] Security Center 5.11.3. This document describes the recommended integration deployment as validated by IONODES and a sample scenario is demonstrated to illustrate the various deployment steps. System Integrators and End Users should adjust to their specific needs and system environment.

2 Recommended Deployment

2.1 Layout

A typical deployment scenario, shown in the diagram below, includes the following:

- PERCEPT Body Camera,
- PERCEPT Docking Station,
- Wi-Fi Access Point,
- Virtual Private Network (VPN) server,
- Local Area Network (LAN) infrastructure, and
- Local Video Management Software (VMS), Genetec[™] Security Center (GSC)





The PERCEPT Body Camera can technically record directly to GSC through 4G LTE or Wi-Fi streaming, but this is not recommended due to bandwidth constraints. The recommended configuration consists of setting up two (2) video stream settings; an on-demand low-bitrate live stream enabled over 4G LTE and Wi-Fi, and a high-bitrate recording stream saved to the camera's internal storage and later transferred to GSC Archiver via the Docking Station's wired Ethernet.

Note: Although the diagram above shows the Wi-Fi Access Point and Docking Station connected to the LAN infrastructure, these can also connect to the internet. In such a configuration, they reach the LAN infrastructure via the VPN, enabling live video and recording transfer from a remote location with internet access.



2.2 Available Functionalities

The table below summarizes functionalities available with the deployment detailed in this guide.

Functionality	Remark
Low-bitrate Live Audio & Video triggered from	Live stream on-demand to minimize Wi-Fi/LTE data usage
Genetec™ Security Desk and Web Client	
Two-way audio communication using Genetec™	Known issue with Push-to-talk on some versions of GSC.
Security Desk	Contact Genetec Support for update
High-bitrate Audio & Video Recording saved on	
device Edge Storage (SD card)	
Automatic Edge Storage transfer of Video to GSC	Audio transfer to GSC Archiver not supported
Archiver	
Date / Time synchronization	With NTP server common to GSC and PERCEPT
Firmware updates from GSC	
Automatic switching between Docking Station, Wi-	With VPN server/router
Fi, and LTE	
End-to-end Encryption	With VPN server/router



3 Configuring the PERCEPT Body Camera

Start by initializing the PERCEPT Body Camera's network connectivity with GSC via Wi-Fi. Refer to the PERCEPT Quick Start Guide for network initialization instructions.

Note: Instructions in this guide assume the PERCEPT Body Camera's initial state is set to factory default. If the body camera was previously used, it is strongly advised to reset it before integrating it with GSC.

3.1 Deploying Multiple PERCEPT Body Cameras

The PERCEPT Body Camera has multiple configuration settings. To avoid the risk of human error when deploying many cameras, it is recommended to start by configuring and validating a single camera.

Once the configuration is fully validated, the IONConfigTool utility (link IONConfigTool - IONODES) can be used to export its configuration then import it to other cameras. All configuration parameters are exported/imported except users and credentials, network settings and media at-rest encryption key. These must be re-entered manually after the import.

3.2 Configure Networking

To integrate with GSC, the PERCEPT Body Camera and LAN infrastructure shall be configured for each camera to always obtain the same IP address on all network interfaces; Wi-Fi, Docking Station, and VPN. If the Wi-Fi and Docking Station always connect to the video LAN, setting static IP addresses for these interfaces may be appropriate.

However, static IP addressing can prevent connecting with other networks to access the video LAN via VPN. For that reason, it is recommended to keep the camera's network interfaces to DHCP and configure the VPN router and/or video LAN DHCP server to hand a reserved IP address to each camera. This is further detailed in section 4 below.

3.2.1 Configure Cellular

All PERCEPT Body Cameras include a SIM card that can be activated at any time. Contact your IONODES reseller to activate a data plan.

3.2.2 Configure Cellular Data Usage

To better control data usage, the PERCEPT Body Camera can be configured to block different types of data over cellular links.

≡			PERCEPT-BC100 v0.1.2.3 online	anvif-user
A	Dashboard	CONFIGURATION		
0	Configuration 1	System Network Video Microphone Speaker Recorder Integration		
¥	Peripherals	> NETWORK INTERFACES		
a .	Live Viewer	✓ CELLULAR 3		
٠		Network Data Usage SIM 1 SIM 2		
8				
٢	Maintenance	Block the following types of data over cellular		
		Audio & Video Streaming		
		Recorded Audio & Video Clips		
0		System Information Files		
		✓ Firmware Updates		
		Sampling rate for the metadata streaming. Set to 0 to deactivate a data type		
		GPS: 0 (0 - 3600) sec		
		System Resources: 0 (0 - 3600) sec		

- 1. From the **Configuration** page
- 2. Select the Network tab
- 3. Expand the CELLULAR section and configure parameters in the Data Usage tab
 - a. Uncheck Audio & Video Streaming to allow live streaming over cellular
 - b. Check Recorded Audio & Video Clips to block Edge storage transfer over cellular
 - c. Check **System Information Files** to block troubleshooting log download over cellular
 - d. Check Firmware Updates to block firmware upload over cellular
 - e. Set sampling rate to **0** for both **GPS** and **System Resources** to block metadata streaming over cellular

Note: Settings above are intended to keep cellular data to strict minimum to achieve functionalities of this deployment scenario. Other data types can be allowed based on individual use case.

Note: It is recommended to disable metadata because the PERCEPT Body Camera integration with GSC does not currently use it. Future revisions are planned to include use cases for metadata.

3.2.3 Configure Wi-Fi Data Usage

PERCEPT Body Cameras can be configured to block media playback and metadata streaming over Wi-Fi. This impacts Edge Storage transfer since it is achieved through media playback. Playback can take up all the available bandwidth of a Wi-Fi network, especially when multiple camera users return to a central location at the end of a shift.

GSC Archiver can be configured to limit edge storage concurrent jobs and bandwidth, or playback can be disabled over Wi-Fi altogether from the PERCEPT Body Camera Web UI. The latter is recommended when deploying with PERCEPT Docking Stations. Edge storage transfers will be performed exclusively over docking stations' wired Ethernet port.

≡	IO NODES	PERCEPT-BC100 v0.1.2.3 🍰 onvif-user online
A	Dashboard	CONFIGURATION
0	Configuration	System Network Video Microphone Speaker Recorder Integration
ł		> NETWORK INTERFACES
₽.	Live Viewer	> CELLULAR
•		> HOST NAME CONFIGURATION
ô		
ł	Maintenance	Media Metadata 3 GPS: 0 (0 - 3600) sec Y Prevent Media Playback Over a Wireless Connection System Resources: 0 (0 - 60) sec
		> HTTP CONFIGURATION
		> DISCOVERY
		> RTSP CONFIGURATION
		> MULTICAST
		➤ MISCELLANEOUS PORTS

- 1. From the **Configuration** page
- 2. Select the Network tab

- 3. Expand the **STREAMING** section and check **Prevent Media Playback Over a Wireless Connection** in the **Media** tab
- 4. Select the **Metadata** tab and set both **GPS** and **System Resources** sampling to **0** to disable metadata streaming

3.2.4 Configure Docking Station(s)

When deploying with PERCEPT Docking Station(s). It is recommended to disable live streaming and playback over Wi-Fi when docked.

≡			PERCEPT-BC100 v0.1.2.3 online	anvif-user
		CONFIGURATION		
o	Configuration	System Network Video Microphone Speaker Recorder Integration		
		> GENERAL		
₽.	Live Viewer	> NTP CONFIGURATION		
•		> SECURITY		
		> DEVICE		
	Maintenance	> WEARER ID		
		✓ Enable Online Mode		
		The Ethernet connection is activated when thresholds are reached.		
		Minimum Battery Level: 20 (20 - 50) %		
		Minimum battery level to allow the online mode.		
		Starting Online Mode 20 (10 - 30) % Offset:		
		Online mode will be activated only when the battery reaches the minimum battery level plus this offset.		
		Network Transfer 300 (120 - 600) sec		
		Timeout to switch in charging mode if no playback activity is running.		
		Charging Timeout: 1800 (600 - 2700) sec		
		Timeout in charging mode to switch in online mode.		
		Allow Live Media Streaming When Docked		
		Allow Recorded Playback and Clip Download Over WIFI When Docked		

- 1. From the **Configuration** page
- 2. Select the **System** tab



- 3. Expand the DOCKING STATION section and configure parameters as follows
 - a. Check Enable Online Mode
 - b. Uncheck Allow Live Media Streaming When Docked
 - c. Uncheck Allow Recorded Playback and Clip Download Over Wi-Fi When Docked
- Note: Edge storage transfer can create bandwidth surges of more than 200Mbps when body cameras start offloading data. Ensure that the network can handle the increased traffic. GSC Archiver advanced settings (Resources->Advanced settings) can be adjusted to limit simultaneous edge storage jobs and throughput based on system scale and capacity.



3.3 Configure Video

3.3.1 Disable orientation metadata

The PERCEPT Body Camera includes orientation metadata used by some client software to stabilize dewarped video. This feature is not supported by GSC and must be disabled in the body camera.

≡			PERCEPT-BWC v10.3.0.12 Convif-user
ń		CONFIGURATION	
o	Configuration	System Network Video Microphone Speaker Recorder Integration	
Ŷ			
æ		← GENERAL	
۲			
8			
		 Include resolution in thermal throttling Automatically adjusts frame rate in low light condition 	
		Force 25 Fps On The Sensor	
		3 Orientation Enable	
		> PROFILE 1 H264, 2.3 MP; 2000 KBPS, 15 FPS	
		> PROFILE 2 H265, 8.3 MP, 4096 KBPS, 30 FPS	
		> PROFILE 3 MJPEG, 2:3 MP, 2 FPS, 85 %	

- 1. From the **Configuration** page
- 2. Select the Video tab
- 3. Uncheck the **Orientation Enable** box



3.3.2 Video profiles

The PERCEPT Body Camera supports two H.264/265 video encoder profiles and one MJPEG profile. Each profile enabled in the camera will be accessible to GSC.

≡	IO NODES		PERCEPT-BC100 v10.7.2.6 Administrator
ń			
o	Configuration	System Network Video Microphone Speaker Recorder Integration	n
ψ			
₽.		> GENERAL	
•		✓ PROFILE 1	
â		H264, 6 MP, 8000 KBPS, 30 FPS	
۶		Encoder Type: H264	
		Resolution: 6 MP	
		Frame Date: 20	
		3 France Via and Via	
		Kbps	
		Set Oplimal Target Bit Rate	
		Show Advanced Settings	
		▶ PROFILE 2 H264, 1 MP, 800 KBPS, 10 FPS	
		▶ PROFILE 3 MJPEG, 2.3 MP, 5 FPS, 50 %	

- 1. From the **Configuration** page
- 2. Select the Video tab
- 3. Enable and configure each video profile. Recommended settings are:
 - a. PROFILE 1 (Recording Stream):
 - i. Encoder Type: H264
 - ii. Resolution: 6 MP
 - iii. Frame Rate: 30 fps
 - iv. Target Bit Rate: 8000 kbps
 - v. Intra Interval: 240 frames
 - vi. Rate Control: Variable Bitrate
 - vii. Profile: Main
 - viii. VBR Aggressiveness: Moderate



- b. PROFILE 2 (Live Stream):
 - i. Encoder Type: H264
 - ii. Resolution: 1 MP
 - iii. Frame Rate: 10 fps
 - iv. Target Bit Rate: 800 kbps
 - v. Intra Interval: 30 frames
 - vi. Rate Control: Variable Bitrate
 - vii. Profile: Main
 - viii. VBR Aggressiveness: Moderate
- c. PROFILE 3 (for PERCEPT Web UI only):
 - i. Encoder Type: MJPEG
 - ii. Resolution: 2.3 MP
 - iii. Frame Rate: 1 fps
 - iv. Rate Control: Fixed quality
 - v. Quality: 50
 - vi. Multipart Compliant: Enabled
- Note: The *Encoder Type* (codec) and profile's Enabled status are detected by GSC when enrolling the body camera. These settings must therefore be configured in the PERCEPT Body Camera before enrolling it to GSC. Changing *Encoder Type* requires rebooting the device.
- Note: Once enrolled in GSC, video profile settings such as resolution, frame rate, etc shall be configured from within GSC Config Tool.
- Note: H.264 is recommended for users that intend on viewing streams from Genetec[™] Web Client without GSC Media Gateway expending computing resources for transcoding. Video profiles can be configured with H.265 codec if Web Client or transcoding resource limitations is not of concern.



3.4 Setup local recording on the body camera

≡	IO NODES		PERCEPT-BC100 v0.1.2.3 🀣 administrator online
ń		CONFIGURATION	
o	Configuration	System Network Video Microphone Speaker Recorder Integration	
Ŷ		3 General Media Recording Image Recording GPS Recording	
а,			
•		> GENERAL	
â			
۶			
		Video Profile: Profile 1 (H.264) Video Profile	
		Enable Pre-Recording	
		Video Profile: Profile 2 (H.264) 🗸	
		Duration: 60 (30 - 120)sec	
		*The pre-recording duration may be shorter than that configured if the video video bit rate is high.	
		✓ Enable Post-Recording	
		Duration: 60 (30 - 300)sec	
		Mute Audio	

- 1. From the **Configuration** page
- 2. Select the **Recorder** tab
- 3. Select the Media Recording subtab, Video Recording section
- 4. Select the Video Profile for edge/onboard storage recording (**Profile 1** for recording throughout this guide)
- 5. Enable Pre/Post-Recording as required and set their duration. The Pre-Recording Video Profile shall be set to the low bitrate live streaming profile (**Profile 2** in this guide)

Note:	When Pre-Recording is enabled, the camera is constantly encoding and buffering video. If Pre-
	Recording is not required, disabling it significantly increases battery life. If Pre-Recording is set
	to the high bitrate profile, the camera will overheat in certain environmental conditions.

Note: To prevent unauthorized usage of locally recorded media in case of loss or theft, the camera features AES-256 encryption for at-rest files.

≡	IO NODES		PERCEPT-BC100 v0.1.2.3 📥 administrator online
		CONFIGURATION	
0	Configuration	System Network Video Microphone Speaker Recorder Integration	
		General Media Recording Image Recording GPS Recording	
		✓ GENERAL 6	
		Encryption Key:	
		Confirm Encryption Key:	
		> VIDEO RECORDING	9
			Save

- 6. Under Configuration, Recorder, Media Recording tab, expand the General subtab
- 7. Select the Security section
- 8. Enter a password for AES-256 encryption of at-rest local media recording (enter and confirm **Encryption Key**). There is no password policy or complexity requirement.
- 9. Save

3.5 Setup time synchronization

Time synchronization ensures media recorded on PERCEPT Body Cameras' internal storage and later transferred to GSC are accurately timestamped. This is achieved through network time protocol (NTP) configuration. NTP settings can be entered manually in the PERCEPT Body Camera configuration page or pushed automatically from GSC.



3.5.1 Setting NTP in PERCEPT Body Camera

≡	IO NODES	PERCEPT-BWC v10.3.0.12 🍰 administrator online	
		CONFIGURATION	
0	Configuration	2 System Network Video Microphone Speaker Recorder Integration	
	Peripherals	> GENERAL	
₽.	Live Viewer	✓ NTP CONFIGURATION	
٠		NTP Server Address: 128 138 140 50	
	Maintenance	> SECURITY	
		> DEVICE	
		> DOCKING STATION	
		> FLASHLIGHT	

- 1. From the **Configuration** page
- 2. Select the **System** tab
- 3. In the **NTP Configuration** section, enter the IP address of the network time server used by GSC to synchronize clocks



3.5.2 Pushing NTP Settings from GSC

GSC Archiver Extensions include NTP server settings. When these settings are non-null, GSC will automatically push NTP server settings to connected devices, including PERCEPT Body Cameras.



- 1. Select the Archiver where the PERCEPT Body Camera is or will be enrolled
- 2. Select the Extensions tab
- 3. Click on NTP settings...
- 4. In the **NTP settings** pop-up window, enter the IP address of the network time server used by GSC to synchronize clocks then click **OK** and **Apply**



3.6 Create a new dedicated ONVIF user (recommended)

The default administrator account can be used for integrating the body camera with GSC. However, it is recommended to create a dedicated ONVIF user account for this purpose. The role "Superuser" gives the account permissions for all functions supported from GSC.

≡								PERCEPT-BWC online	v10.3.0.12 🔒	administrator
		SECURIT	Υ							
		USER ACCC	OUNTS							
		Users:				Cr	eate User 2			
						Re	emove User			
		NEW USER					ssw	ord		
â	Security 1	Username:	onvif-user		3					
		Password:								
		Confirm:								
			The passwor types of char special chara	d must have from 8 to acters from: numeric cter (!@#\$%*()+=).	o 32 characters and (0-9), lowercase (a-:	must contain a z), uppercase (t least 3 (A-Z) and			
		Role:	User Power user Super user Administrato	r 5			ət le =).	east 3 types of character	s from: numeric	(0-9),
					<u>6</u> Cr	eate User	Cancel			

- 1. Once logged into the PERCEPT Body Camera's Web UI, click on the Security page
- 2. Click on the Create User button
- 3. In the New User pop-up window, enter Username
- 4. Enter Password and repeat it to confirm
- 5. Select Super user Role
- 6. Click on Create User

Note: Configuration detailed in this guide shall be made using an 'Administrator' account, the dedicated ONVIF user is to enroll the PERCEPT Body Camera in GSC.

4 Configuring VPN

This section details VPN requirements, including a practical example.

4.1 VPN requirements

- <u>Protocol</u>: The PERCEPT Body Camera supports VPN protocol L2TP/IPSec with Pre-shared Key (PSK). VPN function is always-on; it connects when it can reach the VPN server.
- <u>Tunnel# and Bandwidth</u>: This protocol encrypts VPN tunnels. When assessing a VPN server (hardware or software), maximum number of VPN tunnels and encrypted bandwidth supported shall cover the number of PERCEPT Body Cameras deployed.
- <u>Public Static IP address</u>: The VPN server or router shall connect to the internet with a public static IP address. Port forwarding for the L2TP/IPSec protocol shall be configured when the VPN server is connected behind another internet router.
- <u>Address reservation</u>: VPN solution shall provide a mean to assign specific IP addresses to each device. This can be implemented by having a distinct VPN user for each device and assigning a specific IP to each user.

4.2 VPN example

Specific VPN selection and configuration is outside the scope of this guide. This example is included to better illustrate VPN requirements.

This example uses a entry-level hardware VPN router. It supports up to sixteen (16) L2TP VPN tunnels with a throughput of 47.11 Mbps encrypted. The recommended settings in this deployment guide yields ~ 1.0–1.2 Mbps per camera when live streaming audio and video on-demand. Presuming edge storage transfer is not performed remotely through VPN, this entry-level router can accommodate a small-scale PERCEPT deployment.



4.2.1 Configure L2TP server

This router supports configurable WAN/LAN ports. Once the router's basic IP settings and WAN/LAN ports are connected and configured, add an L2TP server.

Status	L2TP Server	L2TP Client	Global Config	Tunnel List			
Quick Setup	2						
Network	L2TP Server Set	tings					
Preferences							3
Transmission							🔂 Add 🤤 Dele
Firewall		ID	WAP	N	IPsec Encryption	Status	Operation
Behavior Control		1	WAN/L	AN1	Encrypted	Enabled	
• VPN							
• IPsec	WAN:		WAN/LAN1	•			
• L2TP 1	IPsec Er	cryption:	Encrypted	•			
• PPTP	Pre-sha	red Kev:	SuperSecretk	(ev	(1-128 characters)		
OpenVPN Users	Status:	i de noy i	Enable		(1 120 0.0.0000)		
Authentication	01	Canad					
Services	UK	Cancel			4		
System Tools							

- 1. Expand the **VPN** menu and select **L2TP**
- 2. Select the L2TP Server tab
- 3. Add a new L2TP server

Logout

- 4. Configure the L2TP server then click **OK**
 - a. Select the WAN port that will receive incoming PERCEPT connections
 - b. Select Encrypted
 - c. Pick a secret Pre-shared Key
 - d. Enable the L2TP server



4.2.2 LAN IP address reservation

This router can act as DHCP server or relay. To configure LAN and VPN IP addresses from a single device, the DHCP server function is enabled in our example.

Status	LAN	DHCP Cli	ent List	Address Reser	vation						
Quick Setup	Network	List									
 Network 									3 0		
• WAN											
• LAN 1		ID	Name	Vlan	IP Address	Subnet Mask	DHCP Server	DHCP Relay	Operation		
• IPTV		1	LAN	1	10.190.0.1	255.255.0.0	Enabled	Disabled			
MAC Switch											
VIAN	1	Name: IP Address: Subnet Mask:									
• IPV6	1				0.1						
• USB					.0.0						
Preferences	,	Vlan		1	(1.4095)						
Transmission				-							
Firewall	1	DHCP									
Behavior Control											
VPN	I	DHCP Mode	:	OHCP S	erver ODHCP Re	lay					
Authentication	:	Status:		Enable							
Services	:	Starting IP /	Address:	10.190.0	0.5						
System Tools	1	Ending IP A	ddress:	10.190.0	0.199						
		Lease Time:		2880		minutes (1-2880. The d	lefault value is 120)				
Logout		Default Gate	eway:			(Optional)					
		Dofault Dor	anin:			(Optional)					
			-								
		Primary DN	5:			(Optional)					
	:	Secondary [ONS:			(Optional)					
		Advance	ed Settings								
			oo ootango								
	[OK	Cancel]							

- 1. Expand the **Network** menu and select **LAN**
- 2. Select the LAN tab
- 3. Click Add
 - a. Enter LAN network settings
 - b. Enable **DHCP Server** and configure its settings



						4					
►	Status	LA	N	DHCP Client List	Ad	dress Reservation					
►	Quick Setup										
	Network	Ad	dress R	eservation							
	• WAN									6	
	• LAN									•	Add 🔁 Delete
	• IPTV			ID	м	IAC Address		IP Address	Description	Status	Operation
	• MAC			1	C4.4	1 27 52 DA 40		10 100 1 1	DEDGEDT TO	Frabled	
	Switch			1	04-4	1-37-33-DA-4C		10.190.1.1	PERCEPT-TS	Enabled	
	VLAN										
	• IPV6		M	AC Address:		C4-41-37-53-DA-	-4C				
	• USB		IP	Address:		10.190.1.1					
►	Preferences		D	escription:	PERCEPT-TS			(Optional)			
►	Transmission		51	atue		🖌 Enable					
►	Firewall										
►	Behavior Control			OK Car	ncel			•			
•	VPN										
•	Authentication										
►	Services										
•	System Tools										
	Logout										

- 4. Select the Address Reservation tab
- 5. Click Add
- 6. Enter the PERCEPT Body Camera's MAC Address and desired IP Address then Enable

Note: MAC address can be found on the PERCEPT Body Camera Web UI's Dashboard or on its OLED display by repeated short presses on the power button to cycle through status info.



4.2.3 VPN IP address reservation

This router assigns IP addresses to VPN clients. Each VPN user can be assigned to a specific VPN IP pool. By creating a single-address VPN IP pool and a VPN user for each PERCEPT Body Camera, a connection from a specific VPN user is always assigned the same IP address.

▶ Status	VPN IP	Pool					
Quick Setup							
Network	VPN IP P	ool List					•
Preferences							
IP Group							
Time Range		ID	1	P Pool Name	Starting IP Address	Ending IP Address	Operation
VPN IP Pool		1	C.	4413753DA4C	10.190.1.1	10.190.1.1	
Service Type							
Transmission							
Firewall]	IP Pool Na	me:	C4413753DA4C			
Behavior Control	5	Starting II	Address:	10.190.1.1			
► VPN	E	Ending IP	Address:	10.190.1.1			
Authentication		ОК	Cancel	1	3		
 Services 							
System Tools							

- 1. Expand the **Preferences** menu and select **VPN IP Pool**
- 2. Click Add

Logout

3. Pick an **IP Pool Name** and set the **Starting** and **Ending address** to the same address reserved on the LAN DHCP server for this PERCEPT Body Camera. To ease configuration in this example, the IP Pool Name is set to the MAC address of the camera.



►	Status	User	۶Ì											
►	Quick Setup													
►	Network	User	Acco	unt List										
►	Preferences													
►	Transmission										U	Add 🖵 Delete		
►	Firewall			ID	Account Name	Protocol	Local IP Addre	ss I	P Address Pool	Network Mode	Remote Subnet	Operation		
►	Behavior Control			1	C4413753DA4C	L2TP	10.190.0.1	C	4413753DA4C	Client-to-LAN				
	VPN								7					
	• IPsec		A	ccount l	Name:	C441375	53DA4C							
	• L2TP													
	• PPTP		Pe	issword	•	Low	Middle High							
	OpenVPN		Pr	otocol:	tocol:		col: L2		L2TP					
	• Users 🛛 👍					10,100								
►	Authentication		LC	ocal IP /	Address:	10.190.0	J.1							
•	Services		IP	Addres	ss Pool:	C441375	53DA4C 🔻							
►	System Tools		D	NS Add	ress:	10.190.0	0.1							
			N	etwork	Mode:	Client-to	-LAN 🔻							
	Logout		м	ax Coni	nections:	1		(1-100)						
				ОК	Cancel			6						

- 4. Expand the VPN menu and select Users
- 5. Click Add
- 6. Create and configure the VPN user:
 - a. **Account Name**: Pick a unique VPN username for each PERCEPT Body Camera. In this example, it is set to the MAC address of the camera
 - b. Password: A password for this VPN user (can be the same for all users)
 - c. Protocol: L2TP
 - d. Local IP address: LAN IP address of the VPN router
 - e. **IP address Pool**: IP Pool created in previous step for this PERCEPT Body Camera. In this example, it is the MAC address of the camera
 - f. DNS address: LAN IP address of the VPN router
 - g. Network Mode: Client-to-LAN
 - h. Max Connections: 1

4.2.4 Configure PERCEPT VPN Settings

PERCEPT VPN settings shown are based on the VPN IP address reservation example above.

≡	IO NODES	PERCEPT-BC100 v0.1.2.3 And an and a second s
A		CONFIGURATION
o	Configuration	System Network Video Microphone Speaker Recorder Integration
Ψ		
а.	Live Viewer	Wi-Fi Ethernet VPN
•		
â		VPN (4)
۶	Maintenance	✓ Enabled
		VPN type: L21P/IPSec PSK V
		VPN Server: 192.168.0.101
		L2TP Secret:
		Ipsec Identifier.
		Ipsec Secret:
		Username: C4413753DA4C
		Password:
		IP Address: 10.190.1.1, Subnet Mask: 255.255.255.255, Default Gateway: 0.0.0.0, Primary DNS Server: 10.190.0.1

- 1. From the **Configuration** page
- 2. Select the Network tab
- 3. Expand the NETWORK INTERFACES section and select the VPN subtab
- 4. Enable and configure VPN parameters
 - a. VPN Server: Public static IP address of the VPN router's WAN port
 - b. **IPsec Secret**: L2TP server Pre-Shared Key (set in section 4.2.1)
 - c. **Username**: VPN username (set in section 4.2.3, MAC address of the PERCEPT Body Camera in this example)
 - d. Password: VPN user password (set in section 4.2.3)

5 Integrating the PERCEPT Body Camera in GSC

5.1 Enroll Camera

✿ Config Tool												
Search												
Tasks	1		+ 2	+								
Private tasks			- C		XY2.711	~						
Public tasks	Area view	System	Video	Access control	ALPR	User management	Map designer	Network view	Alarms	Plugins	Remote configuration	Synergis™ IX backup
Tools												
Options	<u>_</u>	-	*									
About	Cardholder	Credential	Hotlist and permit									
	management	management	editor									
				00000		2 D		1				
		Audit to its										
	system status	Audit trails	ACTIVITY trails	nearth history	nearth statistics	inventory	configuration	Archiver events	history	Archiver statistics	details	health history
							1					
		Cardbolder access	Door		Cardbolder	Credential		Wearable camera				
	events	rights	troubleshooter	configuration	configuration	configuration	i o comgutation	evidence				
						Favorites ar	nd recent items					

- 1. In the GSC Config Tool, click on the Tasks page
- 2. Click on Video to add devices



👌 Config Tool 🖉 Video 🚹 🛛	
📚 Roles and units 📼 Archive transfer 🔄 Modules 🖝 Cloud storage 🤇 🗲 🕮	
Search ♥ ♥ DESKTOP-BKKRSOD ♥ Media Gateway ♥ Media Gateway ♥ Media Gateway ♥ Unit Assistant	Manufacture: ONVIF Product type: All IP address: 10.190.1.1 IP address: ID.190.1.1 IP address: ID.190.1.1 IP address: ID.190.1.1 IP address: ID.190.1.1 IP address: ID.1.1 IP address: <
🕂 Video unit 🔻 🕂 Unit enrollment	

- 1. From the Video tab, Roles and units subtab
- 2. Click on the + Video unit to add a device
- 3. From the pop-up Manual add window, select ONVIF from the drop-down list
- 4. Enter the IP address of your PERCEPT Body Camera
- 5. If credentials were changed (as recommended), select **Specific** and enter them
- 6. Click Add or Add and close if adding only one device

Note: The PERCEPT Body Camera can also be added through *Unit enrollment* discovery wizard, using ONVIF as the manufacturer.



5.2 Configure Camera

5.2.1 Identity



- 1. Expand the Archiver and select the newly added PERCEPT Body Camera
- 2. Select the **Identity** tab
- 3. Update its Name and Description
- 4. Apply changes and confirm whether you want to rename related devices as well



5.2.2 Peripherals

					🚺 🔩 📢 🚯 📕 Fri 12:40 PM 📃 🔲 😣
✿ Config Tool ■ Video	×				
Polor and unit	Et Martulas				
		TENCERT-03C			
Search 📍			📰 🖾 🔤	۵	
A S DESKTOP-BKKR5OD			Identity Properties Peripherals	Location	
Archiver	Norra a	State Lastarius Door			
PERCEPT-GSC	PERCEPT-GSC - Microphone - 01	State Logical ID Desc	npuon		
PERCEPT-GSC	Gamer PERCEPT-GSC - Input - 01	Normal			
P Media Gateway	PERCEPT-GSC - Input - 02				
T Media Router	9 CP PERCEPT-GSC - Input - 03				
😴 Unit Assistant	\varTheta 🚱 PERCEPT-GSC - Input - 04				
	PERCEPT-GSC - Input - 05				
	PERCEPT-GSC - Input - 06	Normal			
	PERCEPT-GSC				
	Image: PERCEPT-GSC - Speaker - 01				
4 ()					
0	· · · · · · · · · · · · · · · · · · ·				
📕 Video unit 🗶 🖌 Delata 🔠 Ur	nit encollement 🕋 Lloit 🖛 🔳 Common Comm	ation tool 🔥 Maintenance -			
	eopy conigura				

- 1. With the newly added PERCEPT Body Camera selected
- 2. Select the Peripherals tab
- 3. Select all six (6) Input buttons
- 4. Disable selected inputs then Apply changes



🛇 👘 📭 🕸 🕼 👖 Fri 12:40 PM 📃 🗖 💌

Config Tool Video	×	
😻 Roles and units 💻 Archive transfer	🔁 Modules 🔹 Cloud storage < 🔉 🖿	PERCEPT-GSC
Search 🕴		Rat Bill Control Contr
A convert A convert A convert A convert	Name * PERCEPT-GSC - Microphone - 01 PERCEPT-GSC - Input - 01 PERCEPT-GSC - Input - 03 PERCEPT-GSC - Input - 05 PERCEPT-GSC - Input - 05 PERCEPT-GSC - Input - 06 PERCEPT-GSC - Input - 06 PERCEPT-GSC - Speaker - 01	Sate Logical ID Microphone properties Name: Name: Name: State Ocicical ID Description: Data format: AAC Sampling rate: 224 H2 7 Bit rate: 64 Hotsees Vulticast address: 224 16 17 27: (7) Multicast address: 224 16 17 27: (7) Connection type: Est available Wulticast address: 224 16 17 27: (7) Cancel Apply
	,	

- 5. Select the PERCEPT Body Camera's Microphone 01
- 6. Edit its properties by clicking on the stylus icon
- 7. In the **Microphone properties** pop-up window, edit its audio configuration. The following are recommended for acceptable quality and low bitrate:
 - a. Data format: AAC
 - b. Sampling rate: 32 kHz
 - c. Bit rate: 64 kbps
- 8. Apply to close this window then Apply again in Peripherals window



5.2.3 Video

✿ Config Tool ♥ Video ×				
📚 Roles and units 📼 Archive transfer 🗵	Modules 🔸 Cloud storage < > 📫 📼 PERCEPT-C			
Search 💙		Identity Video Recording V	🔄 🌶 🔷	
A Chiver A PERCEPT-GSC Reciept-GSC Media Gateway Media Gateway Media Router Unit Assistant	Video quality: Resolution: H264 2448 x 2448 Quality: Custom Bit rate: 8000 \$ 10 20 Image quality: 0 \$ 0 10 10 Frame rate: 30 \$ 1 30	2 2 000 kbps 10 % fps	Aways +	
	Key frame interval: 240 0 0 00 Recording frame rate: All frames • Stream usage 5 Live Recording © 0FF Image Image	Low resolution High resolution		
	H.264 - 2 H.264 - 2			
	Boost quality on manual recording (OH) Boost quality on event recording (OH)			
· · · · · · · · · · · · · · · · · · ·	3 1000 H.264 - 1 / 1000 H.264 - 2 / 100 MJPEG - 3 /			
🕂 Video unit 🔻 🏦 Unit enrollment 🔍	📚 Unit 👻 🍺 Copy configuration tool 🛛 🚸 Maintenance 👻			🗢 Cancel 🖌 Apply

- 1. Expend the newly added PERCEPT Body Camera and select its camera device
- 2. Select the Video tab
- 3. Select its primary stream H.264 1
- 4. GSC enrollment automatically increases primary video stream settings to highest supported resolution and fps, and default 4Mbps bitrate. Re-enter Profile 1 parameters entered in section 3.3.2
 - a. Resolution: H.264 2448 x 2448
 - b. Bit rate: 8000 kbps
- 5. Configure Stream usage for this profile to Recording and High resolution only
- 6. **Apply** these changes



🔿 📬 🔁 4) 🐔 👖 Fri 1:35 PM 📃 🗖 💌

Config Tool	× \		
📚 Roles and units 📼 Archive transfer	🖻 Modules 🔹 Cloud storage < > 🛤 📼 PERCEPT		
Search 💡		📰 🙀 🐢 🖾 🐓	•
a 📚 desktop-bkkr50d		Identity Video Recording Video analytics Privacy prot	ection Hardware
Archiver			
A 📚 PERCEPT-GSC	Video quality:		
Law PERCEPT-GSC		Always	
Media Gateway	Resolution: H.264 1024 x 1024	+	
😨 Unit Assistant	Quality: Default settings		
	Bit rate: 800 \$ 10 2		
	Image quality: 0 0 1	00 %	
	Frame rate: 10 1 - 3	0 for	
	Key frame interval: 30 ÷ 0 6		
	Recording frame rate: All frames		
	Stream usage		
	Live Recording Remote	Low resolution High resolution	
	Network settings		
0	H.264 - 1 H.264 - 2 MJPEG - 3		
🕂 Video unit 🔻 🆄 Unit enrollment	🌑 Unit 🗸 🗾 Copy configuration tool 🛛 💠 Maintenance 🕶		

- 7. Select secondary stream **H.264 2** and verify that:
 - a. Profile 2 parameters entered in section 3.3.2 are correctly applied (GSC should not change secondary stream settings during enrollment), and
 - b. All Stream usage other than Recording and High resolution use this profile



5.2.4 Recording

	🕗 🕋 🐻 🕫	👔 💼 Fri 1:42 PM	
--	---------	-----------------	--

🏚 Config Tool 🛛 🖻 Video	×				
📚 Roles and units 📼 Archive transfer	Modules 🔹 Cloud storage < >	PERCEPT-GSC			
Search Y]	Ran Identity N	X= Recording Video analytics	ダ 🌑 Privacy protection Hardware	
Archiver	Recording settings: 🔿 Int	erit from Archiver tom settings	2		
Media Gateway Media Router	Recording modes:	Off ameras are available for live viewing only	•		
😴 Unit Assistant	Automatic cleanup:	after 3 🗘 days			
·(
🗘 🕂 Video unit 🔹 🏦 Unit enrollment	🗣 Unit 👻 🇊 Copy configuration tool	🚸 Maintenance 🕶			4 ⇒ Cancel ✓ Apply

- 1. Expend the newly added PERCEPT Body Camera and select its camera device
- 2. Select the **Recording** tab
- 3. Configure Recording modes to Off
- 4. Apply this change



5.2.5 Video analytics

	_							🕑 🐚 🔩 🕬 🕼 🔳 Fri 1:	52 PM
✿ Config Tool ■ Video	×								
😻 Roles and units 📼 Archive transfer	🔄 Modules 🛛 🔸 Cloud storage	< > 🛤 📼 PERCEPT-GSC							
Search			Identity Video	Recording V	ideo analytics	✓ Privacy protection	🐟 Hardware		
Archiver Archiver Archiver PERCEPT-GSC Media Gateway Media Gateway Media Router Unit Assistant	Motion detection 3 I Visual tracking Image: Security monitoring Fill Image: Security	Motion detection:			2				E Abugs
									6
+ Video unit 🔹 🏦 Unit enrollment	🏶 Unit 👻 🗾 Copy configura	tion tool 🔹 🚸 Maintenance 👻						S Can	cel 🗹 Apply

- 1. Expend the newly added PERCEPT Body Camera and select its camera device
- 2. Select the Video analytics tab
- 3. Select the Motion detection subtab
- 4. Toggle Motion detection to Off
- 5. Apply this change



5.2.6 Panormorph Lens

	_		👘 🍢 🕫 🖍 👖 Fil 202 PM 🔔 🗖 💌
Config Tool	*		
📚 Roles and units 📼 Archive transfer	Modules 🔷 Cloud storage < > 📫 📼 PERCEPT-G		
Search Y Search Search		🖬 🔆 🖝 🖾 🌾 Identity Video Recording Video analytics Privacy protection Handware	
Archiver Control of the second secon	PTZ:	2	
▶ Media Gateway	Speaker: PERCEPT-GSC - Speaker - 01	Configure lens - PERCEPT-GSC	
	Less troe: Panomorth	Camera position: Wall Panomorph Lens Type (RPL): C1ZZV	4
		Manual calibration	
	Video rotation: 0 🔹 👔	Calibrate 5 Manual calibration garameters are used when the automatic calib	ration faits.
		Cancel	6 Ok
·() C			
🕂 Video unit 🔻 🕅 Unit enrollment	🛸 Unit 🔹 🗾 Copy configuration tool 🛛 🚸 Maintenance 🔹		🗢 Cancel 🗹 Apply

- 1. Expend the newly added PERCEPT Body Camera and select its camera device
- 2. Select the Hardware tab
- 3. Set **Lens type** to **Panomorph** and click on the stylus icon to open the **Configure Lens** pop-up window
- 4. Set **Camera position** to **Wall** (best approximation for a wearable camera) and **Panomorph Lens Type (RPL)** to **C1ZZV**
- 5. Click on **Calibrate** button
- 6. Click **Ok**
- 7. Apply this change

6 Configuring Edge Storage Transfer

Configuration made in previous section ensures GSC will connect to the low bitrate live video and audio streams on-demand, and not to the high bitrate recording stream. The speaker stream is only activated when Security Desk users press to talk.

All recordings will be saved on PERCEPT Body Camera's internal storage. This section describes how to configure transfer of these recordings to the GSC Archiver.

				S 🔨 🔩 🕈) 🕋 📑 Fri 2:34 PM 📃 🔲 💌
✿ Config Tool ■ Video	×				
		N 100			
Archive transfe	Cioua storage	/ =			
Transfer group 🔺 Type	e Recurrence	Status Transferred data size Last transfer start	Last transfer end Last transfe	Next transfer	
	Transfer group properties				
		Transfer 2			
	Sources: BRCEPT-GSC				
	A Recurrence: Daily - at 07	: 00 PM 👻 🗹 Until 05 : 00 AM 👻			
	Upon reconnection:				
	Data: 💽 All				
	O Specific				
	Simultaneous transfers	1 🗘			
		Cancel Save			
	L				
2					

- 1. From the Video tab, Archive transfer subtab
- 2. Click on the + to create a new archive transfer group
- 3. From the pop-up **Transfer group properties** window, pick a name for this task
- 4. Select a **Recurrence** for archive transfer (more explanations below)
- 5. Click on the + icon then select all PERCEPT Body Camera(s) in the **Add sources** pop-up window
- 6. Click Save

37

To optimize data usage, recurrence shall be tailored to the expected schedule of PERCEPT Body Camera usage. The transfer group shown above will query body cameras between 19:00 and 05:00 every day and transfer all recordings that have not previously been transferred to the GSC Archiver.

LTE and Wi-Fi data usage configuration set in section 3.2 blocks attempt to retrieve (via playback) recordings while connected wirelessly. Blocked attempts will consume a few kilobytes of wireless data each. It is best practice to schedule archive transfer recurrence at a time range when PERCEPT Body Cameras in that transfer group are expected to be docked, allowing the transfers to proceed over the wired Ethernet connection. Distinct transfer groups can be created for PERCEPT Body Cameras deployed over different time periods / work shifts.



7 Validating the Integration

This section describes key features to validate before deploying in the field over LTE/VPN, or on a large scale.

7.1 On-Demand Streaming

When no Genetec[™] Security Desk, Web Client or Config Tool Client is displaying live audio/video, PERCEPT Body Cameras should not be streaming. This can be verified by the status LED of the body camera being solid blue. In this state, network communication is limited to ONVIF event polling and heartbeat traffic.

LED blinking in alternating red/green indicates it is sending a stream. If this is not expected, double-check that no client application is connected and review configurations detailed in sections 5.2.3, 5.2.4 and 5.2.5.

7.2 Live Streaming

Open Genetec[™] Security Desk (GSD), select Monitoring tab and open a PERCEPT Body Camera. Verify that the live video stream starts. If Panormorph is configured as per section 5.2.6, verify that you can dewarp the video and pan through the scene. If Panomorph is not configured, panning and zooming in the hemispherical image is enabled without dewarping.





- 1. If Panormorph lens is configured, panning and zooming the scene dewarps the image
- 2. Click on the Show stream icon
- 3. Verify that video parameters (resolution, frame rate, bitrate, etc.) correspond to the low bitrate **Live** stream configured in sections 3.3.2 and 5.2.3. It is also possible to verify video parameters for the **Recording** stream, keeping in mind that its high bitrate might not be sustainable over wireless network.
- 4. Enable **Listening** and **Talking**. If computer is equipped with speakers, headphones, or other audio output devices, it shall play audio from the PERCEPT Body Camera's microphone. If equipped with audio input device(s), talking in the computer's microphone shall play on the PERCEPT Body Camera's speaker.

Note: There is a known issue with the **Talking** function on some versions of GSC. If no audio comes out of the PERCEPT Body Camera speaker, ensure the latest updates from Genetec are installed.

After closing all live view streams, verify that the LED status of the PERCEPT Body Camera returns to solid blue, indicating no stream is transmitted over the network.



7.3 Edge Storage Transfer

Create a recording on the PERCEPT Body Camera local storage using its function buttons. Long press on F5 button starts / stops continuous recording, while single press on F1 or F3 creates a fixed-duration event recording.

If edge storage transfer (playback) was disabled over wireless as per section 3.2, insert the PERCEPT Body Camera in a docking station.



To validate Edge Storage transfer execution, wait for the recurring rule to execute, or start it manually.





- 1. From the Video tab, Archive transfer subtab
- 2. Select the Transfer group created in section 6
- 3. Click the play icon to Start transfer for selected transfer groups
- 4. Throughput and transfer size can be monitored during the transfer
- 5. Once the transfer completes, Last transfer status should indicate Completed

Open Genetec[™] Security Desk (GSD), select Monitoring tab and open a PERCEPT Body Camera where a recording was transferred.



- 1. On the timeline, seek to date/time when or right after the recording was started from the PERCEPT Body Camera function buttons
- 2. Click on **Show stream** button and verify video parameters correspond to the high bitrate **Recording** stream configured in section 3.3.2 and 5.2.3.
- Note: If pre-recording is configured as per section 3.4, there will be video recorded prior to the date/time recording was started from the camera's functions buttons. In our example, pre-recording is configured to use Profile 2 (low bitrate live stream) for 60 seconds. This pre-recording duration and its video parameters can be verified at this stage.
- Note: If using Genetec[™] Web Client, perform the same tests as for Security Desk, keeping in mind that Web Client does not support push-to-talk and requires GSC Media Gateway transcoding if video streams are configured with H.265 codec.



7.4 Network Interface Switching

If using only Wi-Fi and docking station, network interface switching between both was already tested in previous steps. This section validates switching between LAN and VPN over Wi-Fi and/or LTE.

If a Wi-Fi network with internet access is available, refer to the PERCEPT Body Camera Quick Start Guide to generate a QR code and connect the body camera to this network. From the camera's OLED display, verify the Wi-Fi connection status, signal strength, and that its IP address is as expected for this network. After a few seconds, VPN shall auto-connect and display its IP address. The VPN IP address shall be the same as the LAN IP address:

₩IFI 10:40 ₩IFI 10:40 ₩VPN 10:40 Signal: Great 192.168.0.1 10.190.1.1

Note: Most Wi-Fi routers will not route VPN traffic from its main Wi-Fi network, back to the public static IP address of the primary internet router it is connected to. This can usually be solved by connecting the PERCEPT Body Camera to the Guest Wi-Fi network of the router.

Network interface switching is automatic, based on the following priority:

- 1. LAN over docking station
- 2. Wi-Fi
- 3. LTE / Cellular

If LTE and VPN are properly configured and activated, switching to VPN over LTE is automatic when LAN and Wi-Fi connections are lost.

Verify live streaming work over VPN as it does over Wi-Fi. If a live stream is displayed on Genetec[™] Security Desk (GSD) when the network interface switches, and Panomorph is enabled for that stream, it may be required to clear and restart that live stream in GSD to re-establish the connection. There is a known issue on some versions of GSD that prevents auto-restart of live stream in certain circumstances.