

IMAGING TECHNOLOGY

RELEASE NOTES

IONODES PLUG-IN FOR MILESTONE

VERSION 1.0.1.0

September 30th, 2022

FIRMWARE 1.0.1.0

RESOLVED ISSUES

- No new resolved issue.

NEW FEATURES

- Added support for the Milestone Imaging Server as a data source. The plug-in supports connecting to a Milestone Onvif Bridge or to a Milestone Imaging Server as a valid data source.

KNOWN ISSUES

- If you physically unplug a live camera, the image on the SDS is going to freeze.

FIRMWARE 1.0.0.3

RESOLVED ISSUES

- Creating a blank SDS entry (all fields empty) no longer causes that SDS entry to be locked and unmodifiable.
- The plugin page now always displays feedback if there are more SDS entries detected than the maximum number allowed by the plugin license.

NEW FEATURES

- No new feature.

KNOWN ISSUES

- No known issue.

FIRMWARE 1.0.0.2

RESOLVED ISSUES

- Fixed a condition preventing the user from adding new Secure Display Stations while in trial.
 - If the number of Secure Display Stations exceeds the number of license activations, the plugin now requests that the extra devices be removed.
-

NEW FEATURES

- No new feature.
-

KNOWN ISSUES

- No known issue.

FIRMWARE 1.0.0.1

RESOLVED ISSUES

- No new resolved issue.

NEW FEATURES

- Added Licensing (contact IONODES Sales for details)

KNOWN ISSUES

- No known issues.

FIRMWARE 1.0.0.0

RESOLVED ISSUES

- No new resolved issue.

NEW FEATURES

- New plug-in for Milestone XProtect that allows camera views from the Smart Client to be replicated on IONODES Secure Display Stations.

KNOWN ISSUES

- No known issues.

INSTALLATION NOTES

- Server requirements:
 - The IONODES Plugin for Milestone works with the following versions of Milestone XProtect:
 - Milestone XProtect Express+ 2021 R2 or later
 - Milestone XProtect Professional+ 2021 R2 or later
 - Milestone XProtect Expert 2021 R2 or later
 - Milestone XProtect Corporate 2021 R2 or later
 - The plugin also requires:
 - Milestone Open Network Bridge


- Server installation:
 - Please see Milestone's documentation on how to install and configure XProtect.
 - Please see Milestone's documentation on how to install and configure the Open Network Bridge.
 - See [Milestone Open Network Bridge | Milestone Documentation 2021 R2](https://doc.milestonesys.com/latest/en-US/portal/htm/chapter-page-onvif.htm) (<https://doc.milestonesys.com/latest/en-US/portal/htm/chapter-page-onvif.htm>)
 - A tutorial from Milestone is also available online:
[Configuring and Using ONVIF - YouTube](https://www.youtube.com/playlist?list=PL6KbBiYxpwh06cAmD3KW7Fe9bv3tQsPX8)
(<https://www.youtube.com/playlist?list=PL6KbBiYxpwh06cAmD3KW7Fe9bv3tQsPX8>)

- Recommended: Create a security role for the Open Network Bridge users
 - See the tutorial from Milestone available online:
[Milestone ONVIF: Create ONVIF Role - YouTube](https://www.youtube.com/watch?v=WiVncjJBDqk&list=PL6KbBiYxpwh06cAmD3KW7Fe9bv3tQsPX8&index=5)
(<https://www.youtube.com/watch?v=WiVncjJBDqk&list=PL6KbBiYxpwh06cAmD3KW7Fe9bv3tQsPX8&index=5>)


- Before installing the plugin:
 - All Milestone clients on the computer must be closed.
 - All Milestone server components on the computer must be stopped.
 - Milestone requires plugins to be installed in a specific folder (**C:\Program Files\Milestone\MIPPlugins** by default) relative to its own installed location. If your Milestone software was installed in a different location, the plugin installation path must be adjusted accordingly.
 - Once the plugin is installed, restart all Milestone server components on the computer.

CONFIGURATION

Once the plugin is installed, a new section appears in the XProtect Management Client:




The plugin also appears in the licensing section of the XProtect server. To activate your license, please contact IONODES Sales.




CONFIGURING THE IMAGING SERVER


- Configuring the IONODES Plugin:
 - Open the Tools menu, then select Options.
 - In the window that appears, find the tab named « IONODES Plug-in »
 - Choose the Imaging Server options in the combo box
 - Fill out the details about the Imaging Server. This information will later be used by the IONODES Secure Display Stations to connect to the Imaging Server.
 - Click OK to save the information and close the window.



- Adding a new Secure Display Station:
 - In the Site Navigation pane, select IONODES Secure Display Stations and select Add New...



- A new window appears.
- Fill out the information about the Secure Display Station, then click OK.




The screenshot shows a dialog box titled "Add IONODES Secure Display Station" with a close button (X) in the top right corner. The form contains the following fields and options:

- Name: R200 - My Office
- Description: This SDS is located in my office.
- IP Address: 10.190.0.186
- Protocol: HTTP (dropdown menu)
- Username: admin
- Password: [masked with dots]
- Imaging Server Connectivity section:
 - Use Default Imaging Server Credentials
 - Server Address: [empty field]
 - Server Port: [empty field]
 - Imaging Username: [empty field]
 - Imaging Password: [empty field]

At the bottom, there are "OK" and "Cancel" buttons.

- The Secure Display Station is then added:



The screenshot shows the "IONODES Secure Display Station Information" window. The left pane shows a tree view with "IONODES Secure Display Station" and "R200 - My Office" selected. The right pane displays the following information:

- Name: R200 - My Office
- Description: This SDS is located in my office.
- Network Configuration:
 - IP Address: 10.190.0.186
 - Protocol: HTTP (dropdown menu)
 - Username: admin
 - Password: [masked with dots]
 - Test Connection button
- Imaging Server Connectivity:
 - Use Default Imaging Server Credentials
 - Server Address: [empty field]
 - Server Port: [empty field]
 - Imaging Username: [empty field]
 - Imaging Password: [empty field]
- Device Information:
 - Status: **Connected**
 - Model: R200
 - Serial Number: R300-3220-6350-0001
 - Firmware Version: 6.8.1.0 build 16355 (3acc07)
 - Display Output 1: **Not Connected**
 - Display Output 2: **Not Connected**



- **IMPORTANT:** When a new Secure Display Station is added, the IONODES plugin retrieves additional information from the device. If the additional information does not appear, then communication could not be established with the device. Until the IONODES plugin can

communicate with the device and obtain the required information, the Secure Display Station will not be available in the IONODES plugin's features.


- Save the new Secure Display Station (File menu -> Save).

- Sending a view to a Secure Display Station:

- In the XProtect Smart Client, a new section appears in the Live section




- In the Views pane, select a view to display
- In the IONODES Plug-in panel, select the Secure Display Station and display output where to replicate the view.
- Click on « Copy view to SDS » to send a copy of the view to the appropriate output of the SDS.
- The Secure Display Station displays the selected view.




- Limitations:
 - The Secure Display Station can display a maximum of 16 tiles per view. Trying to send a view with more than 16 tiles is therefore not allowed.
 - When sending a view to a Secure Display Station, only the camera tiles are reproduced on the SDS. Tiles containing other types of information will be left empty on the SDS.

CONFIGURING THE MILESTONE OPEN NETWORK BRIDGE

- Configuring the IONODES Plugin:
 - Open the Tools menu, then select Options.
 - In the window that appears, find the tab named « IONODES Plug-in »
 - Choose the Milestone Open Network Bridge options in the combo box
 - Fill out the details about the Open Network Bridge. This information will later be used by the IONODES Secure Display Stations to connect to the bridge.
 - Click OK to save the information and close the window.



- Adding a new Secure Display Station:
 - In the Site Navigation pane, select IONODES Secure Display Stations and select Add New...



- A new window appears.
- Fill out the information about the Secure Display Station, then click OK.

The screenshot shows a dialog box titled "Add IONODES Secure Display Station". It contains the following fields and options:

- Name: R200 - My Office
- Description: This SDS is located in my office.
- IP Address: 10.190.190.202
- Protocol: HTTP
- Username: admin
- Password: [masked]
- Open Video Bridge Connectivity:
 - Use Default Bridge Credentials
 - Bridge Username: [empty]
 - Bridge Password: [empty]

Buttons: OK, Cancel

- The Secure Display Station is then added:

The screenshot shows the IONODES interface with the following information:

- IONODES Secure Display Stations:**
 - R200 - My Office
- IONODES Plugin Information:**
 - Name: R200 - My Office
 - Description: This SDS is located in my office.
 - IP Address: 10.190.190.202
 - Protocol: HTTP
 - Username: admin
 - Password: [masked]
 - Open Video Bridge Connectivity:
 - Use Default Bridge Credentials
 - Bridge Username: [empty]
 - Bridge Password: [empty]
 - Device Information:
 - Model: R200
 - Serial Number: R300-3182-8310-0003
 - Firmware Version: 6.7.1.0 build 16243 (6123768)
 - Display Output 1: Connected
 - Display Output 2: Not Connected



- **IMPORTANT:** When a new Secure Display Station is added, the IONODES plugin retrieves additional information from the device. If the additional information does not appear, then

communication could not be established with the device. Until the IONODES plugin can communicate with the device and obtain the required information, the Secure Display Station will not be available in the IONODES plugin's features.


- Save the new Secure Display Station (File menu -> Save).

- Sending a view to a Secure Display Station:

- In the XProtect Smart Client, a new section appears in the Live section



- In the Views pane, select a view to display
- In the IONODES Plug-in panel, select the Secure Display Station and display output where to replicate the view.
- Click on « Copy view to SDS » to send a copy of the view to the appropriate output of the SDS.
- The Secure Display Station displays the selected view.



- Limitations:
 - The Secure Display Station can display a maximum of 16 tiles per view. Trying to send a view with more than 16 tiles is therefore not allowed.
 - When sending a view to a Secure Display Station, only the camera tiles are reproduced on the SDS. Tiles containing other types of information will be left empty on the SDS.